



1 (2).

SAFE-P Air Borne Standard Kit.

One standard kit contains; 1 thigh belt with velcro stripe lock, one textile pocket with lid, 2 velcro stripes, one plastic urine bag (volume roughly 2000 ml) connected to a plastic tubing. One connector to the plastic tubing, 2 uridome size large and medium.

Recommended instruction leaflet;

1. Place the thigh belt around your thigh and fix to suitable pressure by using the belts velcro lock.
2. Open the textile pockets lid and place the plastic bag inside the pocket, enter the plastic tubing through the hole placed in the middle of the pocket lid.
3. Take thereafter the velcro stripes and enter one of them through the left placed hole on the textile lid and the other through the right placed hole on the textile lid. Make sure that the stripes afterwards lay flat and not are twisted.
4. Close the lid against the pockets velcro lock and make sure the lid is locked in its fully wide and free from wrinkles. Let both velcro stripes hang down.
5. Connect the pockets backsides velcro lock to the thigh belts velcro stripe and press the pieces together gently. Make sure that the pockets top part not cross the thigh belts top. **Important Note; In order to avoid unpleasant chafe etc. do not let the textile pocket cross over the thigh belt.**
6. Open the package of uridome – after own choice – medium or large, and place your left hands palm (right hands people) tight against the abdomen and let the penis pass out between the long finger and forefinger make sure that no pubis hair comes out between the fingers. Squeeze by press the fingers together as much as possible, keep the squeeze and roll on the uridome on penis. Keep the squeeze and use the right hand to adjust the uridome so the uridomes inside glue is attached to the skin. Thereafter release the left hand squeeze.
7. Take the plastic tubing for urine purpose and adjust the length to the uridome, not to long = risk for chafe, and not to short = unpleasant feeling. Cut of the tubing. **Important Note; The cut shall be done at the upper side of the flat part of the plastic tubing.**

Clean Analytical System AB

Address: Gårdfarivägen 3 532 38 Skara	Telephone: +46 511-163 70	Fax: +46 511-180 82	E-post: info@casab.se	Website: www.casab.se
--	-------------------------------------	-------------------------------	---------------------------------	---------------------------------

2.

8. Take the plastic connector and twist and press the visual part of the connector into the plastic tubing.
9. Remove the plastic cover from the connector and connect the connector to the uridome on penis. Make sure that the connection is firmly done.
10. Take the pants on and let the two velcro stripes follow. Let the stripes pass between the pants and belts and back over the front side of the belt. Thereafter lock the velcro stripes in suitable position. Adjust and lock the pants belt as usual. Correct fasten velcro stripes, allows fast walking, running etc. without unpleasant movement of the product.

Removing used / full urine bag;

1. Remove the plastic connector from the uridome.
2. Open the textile lid on the textile pocket.
3. Remove the plastic tubing through the lid and lift out the urine bag.
4. Place a new urine bag into the pocket and proceed in accordance to article 2, 4, 7 --- 11 above.

Removing of used uridome:

1. Roll of the uridome from penis.
2. Eventually remaining rests from glue at the skin, can easily be removed by using water and soap.

This instruction leaflet is worked out by CAS AB and shall be treated as a proposal to a simplified instruction. Each user of the product shall of course use the product in accordance to their own comfort.

Clean Analytical System AB

Address: Gårdfarivägen 3 532 38 Skara	Telephone: +46 511-163 70	Fax: +46 511-180 82	E-post: info@casab.se	Website: www.casab.se
--	-------------------------------------	-------------------------------	---------------------------------	---------------------------------